


ROKA CHEST OF DRAWERS

COMPONENTS				
PART NO.	DESCRIPTION	QTY		
A	Тор	1		
В	Floor Bottom	1		
С	Visible Side Left	1		
D	Visible Side Right	1		
E	Back Rail	1		
F	Back	1		
G-V	Drawer sides, back and bottom	16		
W,X,Y,Z	Drawer Door Flat Panel	4		

TOOLS REQUIRED			
Screw driver			
Mallet			
Measuring tape			


HARDWARE				
ITEM	IMAGE	QTY		
Sys5 Cam 3000 15 x 14 mm		18		
Sys5 Quickfit TL2 Dowel 8 x 34		18		
Wooden Dowel Titus 8 x 30 mm		36		
Handle H8429	[4		
Leg DY1017 Matt Black	F	4		
Screws 3.5 x 16MM	S. Contraction of the Contractio	36		
Screws 4.0 x 50MM		17		
F.Ext Slide 35 x 350MM		4		
Anti Tip Safety Strap		2		



GENERAL INSTRUCTIONS

- 1. Confirm that all panels (26) are in the package before assembling.
- 2. Check the white sticker on each panel for the labelling (A-Z).
- 3. Ensure that the panels are laid on a non-abrasive surface when assembling.
- 4. Note that all panel connections are done using the system described below.






For an easy and enjoyable assembly:


Please read the assembly chart completely. Remove all the parts from the carton box and place them on a smooth surface. Make sure you have exactly all the parts and tools listed in the chart. Start assembling the products following the steps on the chart. Please keep the assembly chart for future reference.



TWO PERSON ASSEMBLY REQUIRED.




ASSEMBLY SHEET - ROKA CHEST OF DRAWERS





ASSEMBLY SHEET - ROKA CHEST OF DRAWERS

STEP 13



STEP 14





ASSEMBLY SHEET - ROKA CHEST OF DRAWERS

Prevent furniture tip-over accidents
Secure it! Furniture must be securely attached to the wall. Use the tip-over restraint provided with the product and the right hardware for your wall type. Follow our wall anchoring guide for help.

Never let children climb or hang on doors or shelves.

